

Original PANASONIC Remote Control N2QAYB000228



Original\_PANASON\_50adc03e99b3.jpg



TX26LXD8A, TX32LXD8A, TX32LXD80A, TX32LZD800A, TX37LXD80A, TX37LZD800A, TH42PZ800A, TH42PZ800AA, TH46PZ800A, TH46PZ800AA, TH50PX80A, TH50PX80AA, TH50PZ80A  
 Original Panasonic Remote Control. Rating: Not Rated: 30195 [Ask a question about this product](#)

Description

Original PANASONIC LCD TV Remote Control N2QAYB000228.

Number on Remote Control N2QAYB000228, also know as N2QAYB000496 and N2QAKB000066

Suitable for PANASONIC Models TX26LXD8A, TX32LXD8A, TX32LXD80A, TX32LZD800A, TX37LXD80A, TX37LZD800A, TH42PZ800A, TH42PZ800AA, TH46PZ800A, TH46PZ800AA, TH50PX80A, TH50PX80AA, TH50PZ80A

TH42PX80AA, TH42PZ80A, TH42PZ800A, TH42PZ800AA, TH46PZ800A, TH46PZ800AA, TH50PX80A  
TH50PZ800A, TH50PZ800AA, T  
X-26LXD8A, TX-32LXD8A, TX-32LXD80A, TX-32LZD800A, TX-37LXD80A  
, TX-37LZD800A, TH-42PX80A, TH-42PX80AA, TH-42PZ80A, TH-42PZ800A, TH-42PZ800AA, TH-46  
TH-50PX80AA, TH-50PZ80A, TH-50PZ800A, TH-50PZ800AA  
etc

The PANASONIC model number is usually on the back of your PANASONIC product, or on the front

This remote control is an Original Remote Control from PANASONIC, it is the same as the remote control  
PANASONIC product.

\*Requires 2 x AA Batteries\*

**Please note that the original PANASONIC remote control N2QAYB000228 is no longer available, we are now  
supplying the original PANASONIC remote control N2QAYB000496 (pictured below) as a substitute.**

**The original PANASONIC remote control N2QAYB000496 has all the same buttons and functions as the  
original remote control N2QAYB000228.**



