

Original SONY Remote Control RM-AAU136 RMAAU136 HT-M3 HT-M5 HT-M7



Original_SONY_Re_515a7bfe60219.jpg



HTM3, HTM5, HTM7, STRKM3, STRKM5, STRKM7, HT-M3, HT-M5, HT-M7, STR-KM3, STR-KM5, STR-KM7 Original SONY Home Theatre Remote Control.

Rating: Not Rated Yet

Price
\$ 39.95

[Ask a question about this product](#)

Description

Original SONY AV Home Theatre System Remote Control RM-AAU136, RMAAU136.

Number on Remote Control: RM-AAU136, also known as RMAAU136, 1-490-172-11, 149017211.

Suitable for SONY Models: HTM3, HTM5, HTM7, STRKM3, STRKM5, STRKM7, HT-M3, HT-M5, HT-M7, STR-KM3, STR-KM5, STR-KM7.

The SONY model number is usually on the back of your SONY product, or on the front of your user manual.

Requires 2 x AA Batteries

Please note that the original SONY remote control RM-AAU135 was the remote control originally supplied for the above models, not the RM-AAU136.

The original SONY remote control RM-AAU135 is no longer available from SONY and SONY are now supplying the RM-AAU136 as a substitute.

The original SONY remote controls RM-AAU135 and RM-AAU136 are exactly the same, except the RM-AAU136 is missing the "USB" button.

You can access the USB feature on the receiver by pressing the "Input Selector" on the receivers front panel.