

Original SONY Remote Control RM-AMU166 RMAMU166



Original_SONY_Re_51e38a55b00bf.jpg



FSTGTK17IP, FSTGTK37IP, GTKX1BT, RDHGTK17IP, RDHGTK37IP, FST-GTK17IP, FST-GTK37IP, RDH-GTK37IP, Original SONY Remote Control. Rating: Not Rated. [Ask a question about this product](#)

Description

Original SONY Micro Hi-Fi System Remote Control RM-AMU166, RMAMU166.

Number on Remote Control RM-AMU166, also known as RMAMU166, A-192-072-6A, A1920726A.

Suitable for SONY Models: FSTGTK17IP, FSTGTK37IP, GTKX1BT, RDHGTK17IP, RDHGTK37IP, FST-GTK17IP, FST-GTK37IP, RDH-GTK17IP, RDH-GTK37IP.

The SONY model number is usually on the back of your SONY product, or on the front of your user manual.

This remote control is an Original Remote Control from SONY, it is the same as the remote control that came with your product.

Requires 2 x AA Batteries