

Original SONY Remote Control RM-ED056 RMED056 KDL70R550A



Original_SONY_Re_5205a5027305f.jpg

KDL50R550R, KDL60R550A, KDL70R550A, KDL-50R550A, KDL-60R550A, KDL-70R550A Original SONY Remote Control.SUBSTITUTE RM-ED057 REMOTE CONTROL SUPPLIED. PLEASE READ FULL PRODUCT DESCRIPTION

Rating: Not Rated Yet

Price
\$ 49.95

[Ask a question about this product](#)

Description

Original SONY TV Remote Control RM-ED056, RMED056 now substituted to RM-ED057.

Number on Remote Control: RM-ED057, also known as RM-ED056, RMED056, 1-492-074-11, 149207411.

Suitable for SONY Models: KDL50R550A, KDL60R550A, KDL70R550A, KDL-50R550A, KDL-60R550A, KDL-70R550A.

The SONY model number is usually on the back of your SONY product, or on the front of your user manual.

This remote control is an Original Remote Control from SONY.

Please note the original SONY remote control RM-ED056 is no longer available from SONY and that we are supplying the original SONY remote control RM-ED057 as a substitute.

The original SONY remote control RM-ED057 (pictured below) has all the same buttons and functions of the original SONY remote control RM-ED056, except it is missing the "3D" button.

If the "3D" buttons are important to you, please do not purchase.



Requires 2 x AAA Batteries