

Original SONY Remote Control RM-GD015, RMGD015.



Original_SONY_Re_4e855a0b07d0d.jpg

KDL32EX400, KDL40EX400, KDL-32EX400, KDL-40EX400 Original SONY remote control.

Rating: Not Rated Yet

Price
\$ 49.95

[Ask a question about this product](#)

Description

SONY REMOTES : Original SONY Remote Control RM-GD015, RMGD015.

Original SONY TV Remote Control RM-GD015, RMGD015.

Number on Remote Control: RM-GD015, also known as RMGD015, 1-487-706-11, 148770611.

Suitable for SONY Models: KDL32EX400, KDL40EX400, KDL-32EX400, KDL-40EX400.

The SONY model number is usually on the back of your SONY product, or on the front of your user manual.

This remote control is an Original Remote Control from SONY, it is the same as the remote control supplied with your original SONY product.

Requires 2 x AA Batteries